

THANK YOU FOR CHOOSING VINYL VAC!

To see our complete instructional video use the QR code below or visit the following link.

www.vinylvac.net/instructional-video



If you have any questions regarding your Concentrate Cleaner feel free to contact us at info@vinylvac.net

HOW TO USE CONCENTRATE CLEANER

STEP 1.

POUR THE CONCENTRATE INTO DISTILLED WATER

- Pour the entire **1oz** Concentrate Cleaner into a HALF gallon of distilled water.
- Give the mixture a gentle stir and let sit for 24 hours (this will allow all the ingredients to fully combine.)

STEP 2.

APPLY THE CONCENTRATE CLEANER MIXTURE TO YOUR RECORD

- We recommend pouring the concentrate cleaner mixture into a spray or dropper bottle. This will allow you to easily control how much cleaner you put on each record.
- Once you've applied a generous amount of cleaner on your record, let the cleaner sit for a minute or two.
- Then use a soft paint edger to work the cleaner into the grooves.

STEP 3.

RINSE YOUR RECORD WITH DISTILLED WATER & LET DRY

- Dip a 4 inch foam brush into distilled water and make a pass in one direction around the grooves.
- Dip the foam brush again into distilled water and make a second pass in the opposite direction. (Repeat if you feel necessary)